

FlowLine Series 15, 16, & 17

How to Order

Part Numbering System

Series 15

Gear Operators

| Valve Size | Part Number | Valve Size | Part Number | Valve Size | Part Number |
|------------|-------------|------------|-------------|------------|-------------|
| 2" | 15-00202 | 8" | 15-00208 | 20" | 15-00220 |
| 2.5" | 15-00225 | 10" | 15-00210 | 24" | 15-00224 |
| 3" | 15-00203 | 12" | 15-00212 | 30" | 15-00230 |
| 4" | 15-00204 | 14" | 15-00214 | 36" | 15-00236 |
| 5" | 15-00205 | 16" | 15-00216 | 42" | 15-00242 |
| 6" | 15-00206 | 18" | 15-00218 | 48" | 15-00248 |

Series 16

Manual Overrides

| Valve Size | Part Number |
|------------|-------------|
| 2" - 6" | 16-00226 |
| 8" - 10" | 16-00238 |
| 12" - 16" | 16-00254 |
| 18" - 20" | 16-00280 |
| 24" | 16-00278 |

3 Stage Adapter

| Valve Size | Part Number |
|------------|-------------|
| 2" - 6" | 16-35226 |
| 8" - 10" | 16-35238 |
| 12" - 16" | 16-35254 |
| 18" - 20" | 16-35280 |
| 24" | 16-35278 |

Series 17

Chain Wheels

| Valve Size | Part Number |
|------------|-------------|
| 2" - 6" | 17-32200 |
| 8" - 14" | 17-32290 |
| 16" - 24" | 17-32410 |