

### How to Order

### Part Numbering System

Series	Size	Nema	Voltage	Trav/ Speed	Switches	Controls	Pot.	Local Controls
1	2	3	4	5	6	7	8	9

1 Series	
30	Electric

2 Size			
Size	Torque	Size	Torque
0050	354	0900	9800
0080	885	2600	26600
0100	1416		
0200	2124		
0300	3100		
0400	4425		
0700	7100		

3 Nema Rating	
3	3 IP-66
4	Nema 4
6	Nema 6
7	Nema 7

4 Voltage	
1	120 VAC 60 Hz 1 Ph
2	220 VAC 60 Hz 1 Ph
3	380 VAC 3 Ph
4	440 VAC 3 Ph
5	12 VDC
6	24 VDC
7	220 VAC 3 Ph with Starter
8	380 VAC 3 Ph with Starter
9	440 VAC 3 Ph with Starter

5 Travel / Speed	
1	90°
2	120°
3	135°
4	180°
5	270°
6	5 Second
7	10 Second
8	Special

6 Switches	
0	None
1	1 Limit Switch
2	2 Limit Switches
3	1 Torque Switch
4	2 Torque Switches
5	4 Limit Switches
6	4 Torque Switches
7	2 LS and 2 TS
8	4 LS and 4 TS

7 Controls	
0	None
1	4-20 Standard
2	4-20 with Display
3	Digital / ASI

8 Potentiometer	
0	None
1	0-10K Ohm
2	4-20 MADC

8 Local Control	
1	Local Control Switch
2	Local Control W/ Lights
3	Local Control W/ Starter
4	LC W/ Starter and Relays
5	Intelligent
6	None
7	120 VAC W/ Battery BU
8	24 VDC W/ Battery BU
9	220 VAC Battery BU

**Example:** 120 VAC On/Off  
Nema 4

2 extra switches  
1800" Lbs Torque

Series	Size	Trim
30	200	4112006