# Flowine

# **IOM Manual**

IOM Manual Series 53 SPDT Mechanical



Flow Line Valve and Controls, L.L.C.
110 Main Project Road Schriever, LA 70395
P.O. Box 677 Schriever, LA 70395
Phone 985-414-6004 \* Toll Free 800-815-9226 \* Fax 985-414-6072

www.flowlinevalves.com

# **Installation and Operations Manual Series 53**

#### Installation

- 1. Attach proper mounting bracket to the switchbox housing
- 2. Engage switch box shaft to top of actuator shaft.
- 3. Attach bracket to actuator (finger tight only).
- 4. Cycle the actuator; switchbox and actuator will self-align.
- 5. Tighten bracket to actuator.


# Adjusting the switches

#### Figure 1 CLOCKWISE (VALVE CLOSED)

- 1. Disconnect power prior to opening lid.
- 2. Loosen switchbox cover screws and remove cover.
- 3. Rotate actuator to full clockwise position.
- 4. Push down top cam and turn it clockwise until switch is activated. Release the cam and it will engage on the splined retainer. The spring will maintain cam engagement.

#### Figure 2 COUNTER (VALVE OPEN)

- 1. Rotate actuator to full counter-clockwise position.
- 2. Pull up bottom cam and turn it counter-clockwise until switch is activated. Release the cam and it will engage on the splined retainer. The spring will maintain cam engagement.
- 3. Cycle actuator several times to verify adjustment.
- 4. Place the cover on switch box and tighten in cross pattern. *Note: ensure that the cover's o-ring seal is seated in the o-ring groove.*



# **Electrical Wiring**

- 1. Remove switch box cover.
- 2. Remove protection plug(s) from conduit entries and install conduit or other approved connection means.
- 3. Engage wires in terminal strip using a small screwdriver (1/2" blade). *Note:* terminals 1, 2, & 3 are for the top switch and terminals 4, 5, & 6 are for the bottom switch. *Wiring Diagram is on the inside of the switchbox cover.*

### **WARNING:**

To maintain IP67 weather protection, any unused conduit entry must be closed with appropriate conduit plug. Conduit plugs supplied with the switch box are for transit purposes only.

# 3-D Visual Indicator Setting

- 1. Rotate actuator to closed.
- 2. Loosen the four screws securing the plastic indicator dome and rotate it to show 'CLOSED'. *Note: the dome and rotor can be removed and rotated* ½ turn for OPEN-CLOSE visual indication from the end switchbox.

#### SPDT Mechanical Switch Specifications

- Type: Dry contact snap action roller lever arm
- Contacts: Form-C 125-250 VAC, 15Amp 24 VDC, 3 Amp
- Approvals: UL and CSA Recognized Component